

# TEMPERATURE AND SPEED CONTROL LAB (TSC-LAB)

## Practice 10: Data acquisition with square velocity input

<https://tsc-lab.blogspot.com/2021/06/practice-10-data-acquisition-with.html>

- Blog: <https://tsc-lab.blogspot.com/>
- GitHub: <https://github.com/vasanza/TSC-Lab>
- Matlab functions: [https://github.com/vasanza/Matlab\\_Code](https://github.com/vasanza/Matlab_Code)
- IEEEDataPort: <http://ieee-dataport.org/4138>
- **TSC-LAB configurations**
- `int dutyCycleInitial = 255;`
- `int dutyCycleFinish = 0;`
- `int period = 13000;`
- `int cycles = 50;`
- *1 sample per second*

## Raw dataset preparation


```
clear;clc;%clear all
addpath(genpath('./src'))%functions folders
datapath = fullfile('./data/');%data folder
```

## Raw dataset preprocessing

```
filenames = FindCSV(datapath);%List All CSV files
data=readtable(fullfile(datapath,filenames(1).name));%Select i CSV file
data=table2array(data);
DataNorm = fNormalization(data(:,1));%Normalization
DataFeatures = [max(DataNorm) min(DataNorm) mean(DataNorm)...
    median(DataNorm) rms(DataNorm) std(DataNorm) ];%Feature extraction
```


## Plot Raw TSC-LAB dataset

```
figure
plot(data);xlabel('Samples');ylabel('RPM');
title('Motor Speed');
legend('RPM', 'PWM');
```




## Plot Normalization dataset

```
figure
plot(DataNorm);xlabel('Samples');ylabel('Normalized Values');
title('Normalized data graph');
legend('RPM');
```



## Select a case

```
IN=data(:,end);%temp1  
OUT=data(:,1);%PWM1  
figure  
plot(OUT)  
title('OUT');
```




## System Identification

`ident`

Warning: The "ident" command is obsolete and may be removed in a future release of MATLAB. Use the "systemIdentification" command instead.

Created preference file C:\Users\vasan\Documents\MATLAB\idprefs.mat.  
Type HELP MIDPREFS if you want to move this file.



## Open the Classification Learner

```
%regressionLearner
%classificationLearner
```